

20288_AURICULARES CURNEY

FRONT PART

20288 - Auriculares Curney Manual de instrucciones (Esp)



Recomendamos que lea detenidamente este manual de instrucciones y lo conserve para futuras consultas.

Descripción del Producto:



Especificaciones:

- Versión Bluetooth 5.0 + EDR
- Salida: 10mW
- Distancia de funcionamiento: Hasta 10 metros
- Frecuencia: 20Hz-20 KHz
- SNR: 95dB
- Impedancia: 32ohms
- THD: < 1%
- Batería de Polímero de Litio 150mAh, 3.7V
- Tiempo en funcionamiento: 4-5h
- Tiempo en espera: 20h
- FM Radio: 87 – 108 MHz
- Tarjeta Micro SD: Hasta 32GB
- Formatos de audio admitidos: MP3/WMA/ASF
- Cable USB C incluido
- Cable de audio Jack 3.5mm incluido

Carga:

Utilice para la carga el cable suministrado. Conecte el cable USB a una fuente de alimentación. Conecte el otro extremo del cable en el puerto del dispositivo.

Durante el proceso de carga, el indicador luminoso en color rojo permanecerá encendido. Cuando el proceso de carga haya finalizado, el indicador LED se apagará

Funcionamiento:

Mantenga pulsado el botón para encender el auricular. Los indicadores de luz azul y verde comenzarán a parpadear, lo que indica que el dispositivo está listo para ser emparejado.

Desde el menú Bluetooth de su dispositivo, busque nuevos dispositivos y seleccione "20288" para asociarlo a su teléfono. Una vez asociados correctamente, la luz azul permanecerá fija. Los indicadores seguirán parpadeando con el uso de algunas funciones.

Mantenga pulsado el botón para apagar el auricular.

Tarjeta Micro SD:

Inserte una tarjeta Micro SD en la ranura correspondiente y el auricular reproducirá automáticamente la música de la misma.

Entrada de audio (Line in):

Inserte el cable de audio 3.5mm en el auricular, y conecte el otro extremo en su reproductor mp3 / mp4 / teléfono móvil u otro dispositivo compatible para reproducir música.

Nota: Puede hacer uso de esta función con el auricular tanto encendido como apagado. Cuando conecte el cable de audio mientras está encendido, el auricular se apagará automáticamente y podrá comenzar a reproducir la música.

Radio FM:

En el modo radio, pulse el botón y el auricular buscará automáticamente las emisoras de radio disponibles. Pulse de nuevo para fijar un canal como favorito y pulse y para cambiar de emisora.

Nota: Si la radio no está sintonizada, escuchará interferencias.

Controles:

	<ul style="list-style-type: none"> • Pulse una vez para reproducir/pausar la música • Pulse dos veces para marcar el número de la última llamada realizada. • Pulse una vez para responder/coger una llamada. • Mantenga pulsado para rechazar una llamada.
	<ul style="list-style-type: none"> • Pulse una vez para pasar a la siguiente pista. • Mantenga pulsado para subir el volumen (Oirá un sonido de confirmación cuando se alcance el máximo)
	<ul style="list-style-type: none"> • Pulse una vez para retroceder a la pista anterior. • Mantenga pulsado para bajar el volumen.
	<ul style="list-style-type: none"> • Mantenga pulsado el botón para encender/apagar el auricular. • Pulse una vez para cambiar de función (Bluetooth / FM Radio / Tarjeta Micro SD).

Solución de problemas:

Fallo	Solución
Imposible conectarse a otros dispositivos.	<ol style="list-style-type: none"> 1. Revise si los auriculares siguen en el proceso de búsqueda. Apáguelos y enciéndalos nuevamente. 2. Hay demasiados dispositivos Bluetooth alrededor que causan dificultad en la conexión. Por favor desconéctelos. 3. Asegúrese de que está en "modo asociación"
El sonido es bajo o distorsionado.	<ol style="list-style-type: none"> 4. Revise el volumen de su dispositivo y ajústelo a un nivel adecuado. 5. Recargar la batería.
La música se detiene de vez en cuando.	<ol style="list-style-type: none"> 6. Revise si la distancia efectiva de transmisión de los auriculares es excesiva o si existe algún obstáculo entre los auriculares y el dispositivo Bluetooth.

Advertencias:

1. No lo exponga a la lluvia o entornos mojados.
2. Evite caídas que le puedan generar daños serios.
3. No intente reparar la unidad por sí mismo, contacte con un especialista.
4. Para evitar riesgos, no se deshaga de él de manera inapropiada ya que posee una batería de litio integrada.
5. Límpielo con un trapo seco.
6. No lo instale cerca de fuentes de calor o luz solar directa.
7. No inserte ningún objeto metálico en la unidad, existiría la posibilidad de un cortocircuito.
8. El uso de auriculares a un volumen excesivo puede causar pérdidas de audición.



El símbolo de referencia tanto en el producto como en su manual de usuario, indica que al final de la vida útil de los aparatos eléctricos y/o electrónicos, éstos deberán reciclarse por separado de sus residuos domésticos. Existen medios adecuados para recoger este tipo de material para su correcto reciclaje. Para obtener más información, póngase en contacto con la autoridad local.

Por la presente, Mtko Catal Importaciones S.L. declara que este equipo radioeléctrico es conforme con la Directiva 2014/53/UE. El texto completo de la declaración UE de conformidad está disponible en: www.mtko.es (busque por referencia).

MKTO CATAL IMPORTACIONES S.L. B04267225
Ctra. De Huercal-Overa, s/n. 04640, Pulpi, Almería, Spain.

BACK PART

20288 - Headphones Curney User Manual (Eng)



It is recommended to read this user manual carefully and keep it for future reference.

Product Overview:



Specifications:

- Bluetooth version 5.0 + EDR
- Output: 10mW
- Operating distance: up to 10 meters
- Frequency: 20Hz-20KHz
- SNR: 95dB
- Impedance: 32 ohms
- THD: < 1%
- Lithium polymer battery 150mAh, 3.7V
- Working time: 4-5h
- Standby time: 20h
- Radio FM: 87 – 108 MHz
- Micro USB card: up to 32GB
- Supported audio format: MP3/WMA/ASF
- USB C cable
- Audio cable Jack 3.5mm

Charging:

Use the cable provided for charging. Connect USB cable to a power supply. Connect the other end of this cable into the port of your device

During charging the indicator light will turn red. When the headphones are fully charged, the red indicator light will turn off.

Operation:

Hold the button to power on the headphones. The green and blue indicator light will flash to indicate that the device is ready to be paired.

From the Bluetooth menu of your device, search for new devices and select "20288" to pair. Once they are paired successfully, the blue indicator light will stay on. The light indicators will continue to flash while using some of the functions.

Hold the button to power off the headphones.

Micro SD Card:

When you insert a Micro USB card into the Micro SD slot, the headphone will automatically start playing.

Audio Input (Line in):

Insert the audio cable 3.5 mm into the headphones, and connect the other end of the audio cable into your mp3 / mp4 player / mobile phone or other compatible device to play your music.

Note: This function can equally be used when the headphones are powered on or off. When the cable is plugged in, the headphones will automatically power off, but the music will still play if connected to a device.

FM Radio

In radio mode, press and the headphone will automatically search for radio channels. Press again to select preferred channel and press and to change the channel.

Note: In the case that there is no radio channel programmed you will hear a hiss sound.

Controls:

	<ul style="list-style-type: none"> • Short-press the button to play/pause the music. • Press the button twice to redial the last outgoing phone number. • Short-press the button to answer/end a call. • Long-press the button to reject an incoming call.
	<ul style="list-style-type: none"> • Short-press the button to next song. • Long-press the button to VOL +. (a sound indicates maximum volume)
	<ul style="list-style-type: none"> • Short-press the button to previous song. • Long-press the button to VOL -.
	<ul style="list-style-type: none"> • Long-press to turn ON/OFF the headphones. • Short-press to change the function. (Bluetooth / FM Radio / Micro SD Card).

Troubleshooting:

Fault	Solutions
Unable to pair up with other devices.	<ol style="list-style-type: none"> 1. Check whether the headphones are still on the process of search or switch them off and on again. 2. There are too many Bluetooth devices in the proximity that cause difficulty in connection. Turn off other Bluetooth devices. 3. Make sure your earphones are in "Pairing Mode".
The sound is low or distorted.	<ol style="list-style-type: none"> 4. Check the Bluetooth device's volume and then adjust it to an appropriate level. 5. Recharge the battery.
Occasionally the music stops.	<ol style="list-style-type: none"> 6. Check whether the headphones effective transmission range is exceeded or if there is an obstacle standing between the earphones and other Bluetooth devices.

Warnings:

1. Do not expose this product to rain or damp conditions.
2. Prevent this item from falling as it could cause serious damage.
3. Do not dismantle, repair or modify this product by yourself, contact an authorized specialist.
4. In order to avoid any risk, do not dispose of this product inappropriately or throw it into the fire as there is a built-in Lithium battery.
5. Clean it with a dry cloth.
6. Do not place this item near sources of heat or expose to direct sunlight.
7. Do not insert any metal objects into this device as there is a risk of causing a short circuit in the unit.
8. Excessive sound pressure from earphones and headphones can cause hearing loss.



This symbol both in the product and its user manual indicates that at the end of the devices electrical life, it should be recycled separately from your household waste. There are adequate means to dispose of this material for proper recycling. For more information, contact your local authorities.

Hereby, Mtko Catal Importaciones S.L. declares that this radio equipment is in compliance with Directive 2014/53/EU. The full text of the UE declaration of conformity is available at: www.mtko.es (search on reference).

MKTO CATAL IMPORTACIONES S.L. B04267225
Ctra. De Huercal-Overa, s/n. 04640, Pulpi, Almería, Spain.