

# 5157\_GAMEPAD STATION

<p><b>5157_Gamepad User manual (Eng)</b></p>  <p>It is recommended to read this user manual carefully and keep it for future reference.</p>	<p>1. Power On: Android - Hold down the <b>START/⊕</b> + <b>Ⓐ</b> button until the blue LED is on. iOS - Hold down <b>START/⊕</b> + <b>Ⓑ</b> until the red LED is on.</p> <p>2. Power Off: Hold down the <b>START/⊕</b> until the LED is off.</p> <p>Note: if it hasn't connected with the Bluetooth device after 5 mins, the system will turn itself off automatically. After connecting with the Bluetooth device, if there aren't any operations, the system will turn itself off after 60 mins.</p> <p>3. Pair and connect: after the power is on, the LED indicator will flash. Connect your device to the gamepad by pressing "5157" on the Bluetooth menu. When they have paired and connected successfully, the LED indicator will turn off.</p>	<p><b>5157_Gamepad Manual de instrucciones (Esp)</b></p>  <p>Recomendamos que lea detenidamente este manual de instrucciones y lo conserve para futuras consultas.</p>	<p>1. Encendido: Android - Pulse el botón <b>START/⊕</b> + <b>Ⓐ</b> hasta que la luz de led azul se encienda. iOS - Presione <b>START/⊕</b> + <b>Ⓑ</b> hasta que la luz de led roja se encienda.</p> <p>2. Apagado: Pulse el botón <b>START/⊕</b> hasta que la luz de led se apague.</p> <p>Nota: Si tras encenderlo, el mando no se conecta con un dispositivo Bluetooth después de 5 minutos, este se apagará automáticamente. Si después de conectarse con un dispositivo Bluetooth no se realiza ninguna operación, el sistema de apagará automáticamente tras 60 minutos.</p> <p>3. Conexión: Despues de encenderse, el indicador LED comenzará a parpadear. Conecte su dispositivo al mando vía Bluetooth, pulsando "5157". Si la conexión ha sido satisfactoria, el indicador LED se apagará.</p>
<p>4. KEY Function: Switch the button on the side to "Key". The device operation is one-handed vertical operation (as shown to the right).</p> <p>4.1 Music operation: Open your device's music player. Click play, and use this device to operate. (see controls on the diagram to the right)</p> <p>4.2 Shutter operation: Android - The shutter button on the gamepad will depend on the configuration of your device. iOS - Press the <b>⊕</b> button to take a picture.</p> <p>4.3 Mouse operation: Press <b>START/⊕</b> and <b>Ⓐ</b> at the same time and the joystick's function is now a mouse. <b>START/⊕</b> Button is equivalent to the mouse confirmation key. Press <b>START/⊕</b> and <b>Ⓑ</b> at the same time, this switches to music mode. This option is not available for iOS.</p> <p>4.4 Play books function Game mode: use the joystick to turn page (previous and next) Key mode: use volume +/- to turn page (previous and next) This option is not available for iOS.</p>	<p>5. GAME function: Switch the side button to game. Now, the device is operated horizontally with two hands. (as shown to the right).</p>  <p>Note to iOS. Enter into iOS APP store and search "icade". Here you can find games which support this gamepad.</p> <p><b>5.1 Android Controls</b></p> <p><b>⊕</b> = confirmation button <b>Ⓐ</b> = return button Combination keys: SELECT = <b>START/⊕</b> + <b>Ⓐ</b> L1 = <b>START/⊕</b> + <b>⊕</b> L2 = <b>START/⊕</b> + <b>Ⓑ</b> + <b>⊕</b> R1 = <b>START/⊕</b> + <b>Ⓑ</b> R2 = <b>START/⊕</b> + <b>Ⓑ</b> right joystick = left joystick + <b>START/⊕</b></p>	<p>4. Función KEY: Ponga el botón del lateral en la posición "Key". El uso del mando sería en posición vertical (ver imagen a la derecha).</p> <p>4.1 Reproducción de música: Abra el reproductor de música de su dispositivo. Pulse reproducir y use el mando para operar (ver controles a la derecha).</p> <p>4.2 Disparador remoto: Android - El botón de disparo dependerá de la configuración de su dispositivo. iOS - Pulse el botón <b>Ⓑ</b> para tomar una foto.</p> <p>4.3 Función ratón: Pulse <b>START/⊕</b> y <b>Ⓐ</b> al mismo tiempo y el joystick funcionará como un ratón. El botón <b>START/⊕</b> equivale al botón de confirmación. Pulse <b>START/⊕</b> y <b>Ⓑ</b> al mismo tiempo para volver al modo música. Esta opción no está disponible para iOS.</p> <p>4.4 Función Play libros Modo Game: use el joystick para cambiar de página (previa y siguiente) Modo Key: use las teclas volumen +/- para cambiar de página (previa y siguiente). Esta opción no está disponible para iOS.</p>	<p>5. Función GAME: Ponga el botón del lateral en la posición "Game". El uso del mando sería en posición horizontal (ver imagen a la derecha).</p>  <p>Nota iOS. Entre en APP store y busque "icade". Aquí podrás encontrar juegos que soportan este mando.</p> <p><b>5.1 Controles Android</b></p> <p><b>⊕</b> = botón de confirmación <b>Ⓐ</b> = botón de retroceso Combinación de teclas: SELECT = <b>START/⊕</b> + <b>Ⓐ</b> L1 = <b>START/⊕</b> + <b>⊕</b> L2 = <b>START/⊕</b> + <b>Ⓑ</b> + <b>⊕</b> R1 = <b>START/⊕</b> + <b>Ⓑ</b> R2 = <b>START/⊕</b> + <b>Ⓑ</b> Joystick derecho = joystick izquierdo + <b>START/⊕</b></p>
<p><b>5.1 iOS Controls</b></p> <p>Combination keys: SELECT = <b>START/⊕</b> + <b>Ⓐ</b> L1 = <b>START/⊕</b> + <b>⊕</b> R1 = <b>START/⊕</b> + <b>Ⓑ</b></p> <p><b>Notes:</b></p> <ol style="list-style-type: none"> <li>To Android system, after the devices are connected, the keyboard will not appear.</li> <li>When the power is low, the LED will flash. After connecting the micro USB cable, the red LED will be on to indicate it is charging. When it is fully charged, the LED will turn itself off.</li> <li>If the gamepad can't connect successfully to other devices, you must reset it (reset button on the back)</li> </ol>	<p><b>Specifications:</b></p> <ul style="list-style-type: none"> <li>Bluetooth 4.0</li> <li>Wireless: 3.0 compliant / Distance: 2-10m</li> <li>OS: Android 4.3 or above / iOS 7.0 or above</li> <li>CPU: ARM968E-S core</li> <li>Li-Battery: 180mAh (3.7V)</li> </ul> <p> MADE IN PRC</p> <p>This symbol both in the product and its user manual indicates that at the end of the devices electrical life, it should be recycled separately from your household waste. There are adequate means to dispose of this material for proper recycling. For more information, contact your local authorities.</p> <p>Imported by: MKTO CATAL IMPORTACIONES S.L. Ctra. De Huercal-Overa, s/n, 04640, Pulpi, Almería, Spain.</p>	<p><b>5.1 Controles iOS</b></p> <p>Combinación de teclas: SELECT = <b>START/⊕</b> + <b>Ⓐ</b> L1 = <b>START/⊕</b> + <b>⊕</b> R1 = <b>START/⊕</b> + <b>Ⓑ</b></p> <p><b>Notas:</b></p> <ol style="list-style-type: none"> <li>Para sistema Android, después de conectar ambos dispositivos, el teclado de su dispositivo no aparecerá.</li> <li>Cuando el nivel de la batería sea bajo, la luz de Led comenzará a parpadear. Después de conectar el cable micro USB, la luz de led roja se encenderá para indicar que se está cargando. Cuando esté totalmente cargado, la luz de led se apagará.</li> <li>Si el mando no se puede conectar de forma satisfactoria con otros dispositivos, éste se debe resetear (botón reset en la parte trasera)</li> </ol>	<p><b>Especificaciones:</b></p> <ul style="list-style-type: none"> <li>Bluetooth 4.0</li> <li>Conexión inalámbrica compatible 3.0 / Distancia: 2-10m</li> <li>OS: Android 4.3 o superior / iOS 7.0 o superior</li> <li>CPU: ARM968E-S core</li> <li>Batería de Litio: 180mAh (3.7V)</li> </ul> <p> MADE IN PRC</p> <p>El símbolo de referencia tanto en el producto como en su manual de usuario, indica que al final de la vida útil de los aparatos eléctricos y/o electrónicos, éstos deberán reciclarse por separado de sus residuos domésticos. Existen medios adecuados para recoger este tipo de material para su correcto reciclaje. Para obtener más información, póngase en contacto con la autoridad local.</p> <p>Importado por: MKTO CATAL IMPORTACIONES S.L. Ctra. De Huercal-Overa, s/n, 04640, Pulpi, Almería, Spain.</p>