

# 1441\_COMBA GRIMLUCK\_Manual

## FRONT PART

### 1441 - Comba Grimluck Manual de instrucciones (Esp)



Recomendamos que lea detenidamente este manual de instrucciones y lo conserve para futuras consultas.

#### Descripción del producto:



#### Especificaciones:

- Pantalla LCD con 4 dígitos.
- Contador: Saltos, Distancia recorrida en millas, Distancia recorrida en km, Calorías consumidas.
- Pila LR44 incluida.

#### Instrucciones de uso:

*Sólo la primera vez:* Retire la protección de la pila de su compartimento.

Al usar la comba la pantalla se encenderá automáticamente mostrando el número de saltos realizados. Pulse el *botón de modo* para cambiar los datos mostrados a Distancia recorrida en millas, Distancia recorrida en km, Calorías consumidas.

Pulse el *botón de reinicio* para poner los contadores a 0.

Transcurridos 95 segundos sin uso la pantalla se apagará para ahorrar batería.

#### Advertencias:

1. No lo exponga a la lluvia o entornos mojados.
2. Evite caídas que le puedan generar daños serios.
3. No intente reparar la unidad por sí mismo, contacte con un especialista.
4. Para evitar riesgos, no se deshaga de él de manera inapropiada.
5. Limpielo con un trapo seco.
6. No lo instale cerca de fuentes de calor o luz solar directa.



El símbolo de referencia tanto en el producto como en su manual de usuario, indica que al final de la vida útil de los aparatos eléctricos y/o electrónicos, éstos deberán reciclarse por separado de sus residuos domésticos. Existen medios adecuados para recoger este tipo de material para su correcto reciclaje. Para obtener más información, póngase en contacto con la autoridad local.

MKTO CATAL IMPORTACIONES S.L. B04267225  
Ctra. De Huércal-Overa, s/n, 04540, Puñal, Almería, Spain.



## BACK PART

### 1441 - Skipping Rope Grimluck User Manual (Eng)



It is recommended to read this user manual carefully and keep it for future reference.

#### Product overview:



#### Specifications:

- LCD screen con 4 dígitos.
- Counter: Jumps, Distance in miles, Distance in kilometers, Calories burned.
- Battery LR44 included.

#### Operation:

Once you use the skipping rope the screen will turn on, showing the jumps made. Press again *Mode button* to change data showed between Distance in miles, Distance in kilometers, Calories burned in Kcal.

Press *Reset button* to reset all the counters to 0.

After 95 seconds without use the screen will turn off to save battery.

#### Warnings:

1. Do not expose this product to rain or damp conditions.
2. Prevent this item from falling as it could cause serious damage.
3. Do not dismantle, repair or modify this product by yourself, contact an authorized specialist.
4. In order to avoid any risk, do not dispose of this product inappropriately.
5. Clean it with a dry cloth.
6. Do not place this item near sources of heat or expose to direct sunlight.



This symbol both in the product and its user manual indicates that at the end of the devices electrical life, it should be recycled separately from your household waste. There are adequate means to dispose of this material for proper recycling. For more information, contact your local authorities.

MKTO CATAL IMPORTACIONES S.L. B04267225  
Ctra. De Huércal-Overa, s/n, 04540, Puñal, Almería, Spain.

