

7345_AURICULARES LEMENK

FRONT PART

7345_Auriculares Lemenk Manual de instrucciones (Esp)



Recomendamos que lea detenidamente este manual de instrucciones y lo conserve para futuras consultas.

Descripción del Producto:



Especificaciones:

- Versión Bluetooth 4.2
- Salida: 30mW
- Distancia de funcionamiento: Hasta 10 metros
- Frecuencia: 2.4-2.48GHz
- SNR: 105dB
- Impedancia: 32ohms
- Distorsión: menos del 1%
- Batería de Litio 450mAh
- Entrada: 3.7V
- Tiempo en funcionamiento: 8h
- Tiempo en espera: 180h
- FM Radio: 87 - 108M Hz
- Tarjeta Micro SD: Hasta 16GB
- Formatos de audio admitidos: MP3/WMA/ASF
- Cable micro USB incluido
- Cable de audio jack 3.5 mm incluido

Carga:

Utilice para la carga el cable suministrado. Conecte el cable USB a su ordenador/adaptador de corriente alterna. Conecte el otro extremo del cable con conexión micro USB en el puerto micro USB del dispositivo.

Durante el proceso de carga, el indicador luminoso en color rojo permanecerá encendido. Cuando el proceso de carga haya finalizado, el indicador LED se apagará.

IMPORTANTE: Realice la carga del dispositivo cuando este esté apagado.

Funcionamiento:

Mantenga pulsado el botón **▶|** para encender el auricular. Los indicadores de luz azul y rojo comenzarán a parpadear, lo que indica que el dispositivo está listo para ser emparejado.

Desde el menú Bluetooth de su dispositivo, busque nuevos dispositivos y seleccione "7345" para asociarlo a su teléfono. Una vez asociados correctamente, la luz azul parpadeará.

Mantenga pulsado el botón **▶|** para apagar el auricular.

Tarjeta Micro SD:

Inserte una tarjeta Micro SD en la ranura correspondiente y el auricular reproducirá automáticamente la música de la misma.

Entrada de audio (Line in):

Inserte el cable de audio 3.5mm en el auricular, y conecte el otro extremo en su reproductor mp3 / mp4 / teléfono móvil u otro dispositivo compatible para reproducir música.

Nota: Para usar esta función, el auricular debe estar apagado.

Radio FM:

En el modo radio, pulse **▶|** y el auricular buscará automáticamente las emisoras de radio disponibles. Pulse **▶| V+** y **◀◀ V-** para cambiar de emisora.

Nota: Si la radio no está sintonizada, escuchará interferencias.

Controles:

M	Pulse para cambiar de función. (Bluetooth / FM Radio / Tarjeta Micro SD)
▶ V+	- Pulse una vez para pasar a la siguiente pista. - Mantenga pulsado para subir el volumen. (Oirá un sonido de confirmación cuando se alcance el máximo)
◀◀ V-	- Pulse una vez para retroceder a la pista anterior. - Mantenga pulsado para bajar el volumen.
▶ 	- Pulse una vez para responder/colgar una llamada. - Pulse una vez para reproducir/pausar la música. - Mantenga pulsado para rechazar una llamada. - Pulse dos veces para marcar el número de la última llamada.

Solución de problemas:

Fallo	Solución
Imposible conectarse a otros dispositivos.	- Revise si los auriculares siguen en el proceso de búsqueda. Apáguelos y enciéndalos nuevamente. - Hay demasiados dispositivos Bluetooth alrededor que causan dificultad en la conexión. Por favor desconéctelos. - Asegúrese de que está en "modo asociación"
El sonido es bajo o distorsionado.	- Revise el volumen de su dispositivo y ajústelo a un nivel adecuado. - Recargar la batería.
La música se detiene de vez en cuando.	Revise si la distancia efectiva de transmisión de los auriculares es excesiva o si existe algún obstáculo entre los auriculares y el dispositivo Bluetooth.

Advertencias:

- No lo exponga a la lluvia o entornos mojados.
- Evite caídas que le puedan generar daños serios.
- No intente reparar la unidad por sí mismo, contacte con un especialista.
- Para evitar riesgos, no se deshaga de él de manera inapropiada ya que posee una batería de litio integrada.
- Límpielo con un trapo seco.
- No lo instale cerca de fuentes de calor o luz solar directa.
- No inserte ningún objeto metálico en la unidad, existiría la posibilidad de un cortocircuito.
- El uso de auriculares a un volumen excesivo puede provocar pérdida de audición permanente.



Por la presente, Miko Catal Importaciones S.L. declara que este equipo radioeléctrico es conforme con la Directiva 2014/53/UE. El texto completo de la declaración UE de conformidad está disponible en: www.makito.es (busque por referencia).

MKTO CATAL IMPORTACIONES S.L. B04267225
Ctra. De Huercal-Overa, s/n, 04640, Pulpí, Almería, Spain.

BACK PART

7345_Headphones Lemenk User Manual (Eng)



It is recommended to read this user manual carefully and keep it for future reference.

Product Overview:



Specifications:

- Bluetooth Version 4.2
- Output: 30mW
- Operating distance: up to 10 meters
- Frequency: 2.4-2.48GHz
- SNR: 105dB
- Impedance: 32 ohms
- Distortion: less than 1%
- Lithium battery 450mAh
- Input: 3.7V
- Working Time: 8h
- Standby time: 180h
- Radio FM: 87 - 108M Hz
- Micro USB Card: up to 16GB
- Supported audio format: MP3/WMA/ASF
- Micro USB cable
- Audio cable Jack 3.5mm

Charging:

Use the cable provided for charging. Connect USB cable to computer / AC adapter. Connect the micro USB end of this cable into the micro USB port of your device.

During charging, the indicator light will turn red. When the headphones are fully charged the red indicator light will turn off.

IMPORTANT: Charge the device when it is turned off.

Operation:

Hold the **▶|** button to power on the headphones. The red and blue indicator light will flash to indicate that the device is ready to be paired.

From the Bluetooth menu of your device, search for new devices and select "7345" to pair. Once they are paired successfully, the blue indicator light will flash.

Hold the **▶|** button to power off the headphones.

Micro SD Card:

When you insert a micro SD card into the micro SD slot, the music will automatically start playing.

Audio Input (Line in):

Insert the audio cable 3.5mm into the headphones, and connect the other end of the audio cable into your mp3 / mp4 player / mobile phone or other compatible device to play your music.

Note: To use this function, the headphones must be turned off.

FM Radio

In radio mode, press **▶|** button and the headphones will automatically search for radio channels. Press **▶| V+** and **◀◀ V-** to change the channel.

Note: If there is no radio channel programmed you will hear a hiss sound.

Controls:


M	Short-press to change the function. (Bluetooth / FM Radio / Micro SD Card)
▶ V+	- Short-press the button to next song. - Long-press the button to increase the volume. (When maximum volume is reached, you will hear a notification sound)
◀◀ V-	- Short-press the button to previous song. - Long-press the button to decrease the volume.
▶ 	- Short-press the button to answer/end a call. - Short-press the button to play/pause the music. - Long press the button to reject an incoming call. - Press the button twice to redial the last phone number.

Troubleshooting:

Fault	Solutions
Unable to pair up with other devices.	- Check whether the headphones are still on the process of search or switch them off and on again. - There are too many Bluetooth devices in the proximity that cause difficulty in connection. Turn off other Bluetooth devices. - Make sure your headphones are in "Pairing Mode".
The sound is low or distorted.	- Check the Bluetooth device's volume and then adjust it to an appropriate level. - Recharge the battery.
Occasionally the music stops.	Check whether the headphones effective transmission range is exceeded or if there is an obstacle standing between the headphones and other Bluetooth devices.

Warnings:

- Do not expose this product to rain or damp conditions.
- Prevent this item from falling as it could cause serious damage.
- Do not dismantale, repair or modify this product by yourself, contact an authorized specialist.
- In order to avoid any risk, do not dispose of this product inappropriately or throw it into the fire as there is a built-in Lithium battery.
- Clean with a dry cloth.
- Do not place this item near sources of heat or expose to direct sunlight.
- Do not insert any metal objects into this device as there is a risk of causing a short circuit in the unit.
- Excessive sound pressure from earphones and headphones can cause hearing loss.



Hereby, Miko Catal Importaciones S.L. declares that this radio equipment is in compliance with Directive 2014/53/EU. The full text of the UE declaration of conformity is available at: www.makito.eu (search on reference).

MKTO CATAL IMPORTACIONES S.L. B04267225
Ctra. De Huercal-Overa, s/n, 04640, Pulpí, Almería, Spain.