

ITEM 4088\_ MANUAL DE INSTRUCCIONES

ESPAÑOL

A. Funciones:

1. 4 Funciones combinables: Hora/Fecha, Alarma, Temporizador, Temperatura.
2. Calendario hasta año 2099, muestra año, mes, fecha y día.
3. Temporizador máximo: 99 minutos, 59 segundos
4. Temperatura muestra rango desde -20°C a 40°C (°C – °F)

B. Operativa:

Instalar 2 x 1.5V AAA(R03) pilas en el compartimento de las baterías atendiendo a la polaridad +/-, usar teclas M (Modo) y S (Set) para ajustar.

1. Ajustar hora/fecha

Presionar botón M y el indicador de las horas empezará a parpadear.  
Presionar botón S para seleccionar horas-minutos-meses-día-año.

2. Ajustar alarma

Girar la estación a la posición de Alarma. Presionar botón M y el indicador de la hora empezará a parpadear, presionar botón S para seleccionar hora-minuto.

3. Temporizador

Girar la estación a la posición de Temporizador. Presionar botón M y el indicador de los minutos empezará a parpadear, presionar botón S para seleccionar minutos-segundos.

4. Temperatura

Girar la estación a la posición de Temperatura, la estación mostrará la temperatura local automáticamente. Presionar botón S para cambiar de °C a °F respectivamente.

C. Seguridad:

No exponer el reloj a altas temperaturas, humedad, a la luz directa del sol o al polvo.

ITEM 4088\_ INSTRUCTION MANUAL

ENGLISH

A. Functions:

1. 4 Functions: Time/date, alarm, timer, temperature.
2. Calendar up to year 2099, showing: year, month, date and day.
3. Timer for max: 99 minutes, 59 seconds.
4. Temperature showing scale from -20°C to 40 °C(°C.°F).

B. Operation:

Install 2 x 1.5V AAA(R03) batteries into battery compartment and note the polarity +/- , use M (Mode) and S (Set) button to adjust .

1. Setting time/date

Press M button and the hour indicator will start to flash.  
Press S button to set hour-minute-month-date-year.

2. Setting Alarm

Turn the clock to Alarm display position.  
Press M button and hour indicator will start to flash.  
Press S button to set hour-minute.

3. Timer

Turn the clock to Timer display position.  
Press M button and minute indicator will start to flash.  
Press S button to set minute-second.

4. Temperature

Turn the clock to Timer display position. Clock will display local temperature automatically.  
Press S button to change °C & °F.

C. Security

Do not expose the clock to high temperature, humidity, direct sun light or dust.  
Keep the devise in away from small children.