


6556_TROLLEY HESSOK

FRONT PART

6556_TROLLEY HESSOK



BACK PART



INSTRUCTIONS FOR USE

The lock is pre-set to 0-0-0. To change the code, follow the below instructions:

1. Using a pen or an object with a pointed end, push the red button down and hold it in place.
2. Turn the dials to set each number to your preferred code and release the button. Your new code is now set.
3. For security, rotate the dials so that your code cannot be seen.
4. To open the lock, turn the dials to your selected code and slide the end button in the direction of the arrow.

INSTRUCCIONES DE USO

El código fijado por defecto es 0-0-0. Para cambiarlo, siga estos pasos:

1. Con un objeto con punta, mantenga pulsado el botón rojo.
2. Gire los dígitos hasta seleccionar el código deseado y suelte el botón.
3. Por seguridad, gire los dígitos para que el código fijado no pueda ser visto.
4. Para abrir el cierre, sitúe los dígitos en el código seleccionado, y pulse el botón de apertura en la dirección que indica la flecha.