


21929 - TROLLEY CORBIN



Lock release button(2)
Botón de apertura



Reset button(1)
Botón de desbloqueo

USER INSTRUCTIONS

The default combination code is 0-0-0

To set a new combination code use the following steps:

1. Using a pointed object, push in the reset button (1) until you hear a click sound.
2. Turn the dials to set your own combination code.
3. Press the lock release button firmly (2) in the direction of the arrow until it clicks.
Your new combination code has now been set.

INSTRUCCIONES DE USO:

El código de combinación predeterminado es 0-0-0

Para establecer un nuevo código de combinación, siga los siguientes pasos:

1. Con un objeto puntiagudo, presione el botón de reinicio (1) hasta que escuche un clic.
2. Gire los diales para configurar su propio código de combinación.
3. Presione firmemente el botón de liberación de bloqueo (2) en la dirección de la flecha hasta que haga clic.
Su nuevo código de combinación ya estará configurado.