

ITEM 4629 MANUAL (EN)

1. SPECIFICATION

Power Output: 10w Max

Voice Range: 200m

Power Source: 4 x R14 (not included)

Microphone: Unidirectional

Dimensions: Horn Dis.138mm, Length 217mm

Weight: 0.5 kg without cells

Voltage: 6v

2. OPERATION

Open the Back Cover by pressing the Open Button.

Insert 4 x R14 batteries, (not included) then close the back cover.

Now your megaphone is ready for action.

To activate the megaphone, press the ON/OFF Button on the Back Cover.

Adjust the Volume Control to the desired level using the corresponding button

Press music button to activate this function. To switch off the music, press the same button again, or press the ON/OFF button.

ITEM 4629 MANUAL (ES)

1. ESPECIFICACIONES

Potencia de salida: 10w Max

Alcance: 200m

Fuente de alimentación: 4 x R14 (no incluidas)

Micrófono: Unidireccional

Dimensiones: Diámetro del altavoz 138mm, Largo 217mm

Peso: 0.5 kg sin pilas

Voltaje: 6v

2. USO

Abra la tapa trasera presionando el botón de apertura.

Inserte 4 pilas R14, (no incluidas) luego cierre la tapa trasera.

Ahora su megáfono está listo para funcionar.

Para activar el megáfono, presione el botón ON/OFF de la tapa trasera.

Ajusta el control de volumen al nivel deseado utilizando el botón correspondiente.

Presione el botón de música para activar esta función. Para apagar la música, presione de nuevo el mismo botón o presione el botón ON/OFF