

3594_MINI RADIO PROBE - 9 x 7 cm

3594_MINI RADIO (Esp) MANUAL INSTRUCCIONES

INSTRUCCIONES

1. Conectar los auriculares.
2. Seleccionar "ON" para encender la radio.
3. Seleccionar "OFF" para apagar.
4. Presionar "RESET" para restablecer la frecuencia FM.
5. Presionar "SCAN" para sintonizar una nueva emisora.

ADVERTENCIAS

1. Cuando el sonido sea débil o distorsionado, reemplazar las baterías.
2. Retirar las baterías del dispositivo cuando no se utilice durante periodos prolongados.
3. Evitar el contacto con el agua.

CARACTERÍSTICAS

1. Incluye 2 baterías LR44.
2. Rango de frecuencia: 88 - 108 MHZ.

3594_MINI RADIO (Eng) USER MANUAL

INSTRUCTIONS

1. Insert earphones into earphone jack.
2. Switch "ON" to turn radio on.
3. Turn to "OFF" to turn radio off.
4. Press "RESET" button to reset FM frequency.
5. Press "SCAN" button to search broadcast programming from station to station.

WARNINGS

1. When radio sound becomes weak or distorted, replace battery.
2. Remove batteries from device when storing for extended periods of time.
3. Do not swim with radio or submerge radio in water, otherwise it will become dysfunctional.

SPECIFICATIONS

1. Includes 2 pcs LR44 button cell batteries.
2. FM frequency: 88 - 108 MHZ.