


# 5767\_ALTAVOZ CLARMUNT


## FRONT PART



**5767\_Altavoz Clarmunt**  
**Manual de instrucciones (Esp)**

Recomendamos que lea detenidamente este manual de instrucciones y lo conserve para futuras consultas.

**Descripción del Producto:**



1. Indicador luminoso
2. Puerto USB
3. Entrada Micro USB
4. : Reproducir/Pausar/Responder/Colgar/Rechazar/Reclamada/Buscar emisoras
5. +: Pista siguiente/Subir el volumen/Cambiar de emisora
6. -: Pista anterior/Bajar el volumen/Cambiar de emisora
7. : Encender/Apagar/Cambiar de Modo
8. Entrada Jack: Función AUX/ Line In
9. Tarjeta Micro SD

**Especificaciones:**

- Versión Bluetooth 3.0
- Voltaje de carga: 5V
- Batería de Litio de 400mAh, 3.7V
- Frecuencia: 280Hz – 16KHz.
- Tiempo de funcionamiento: hasta 3 horas.
- Distancia de funcionamiento: hasta 10M.
- Impedancia: 4 ohms
- Potencia: 3W
- Distorsión: Menos del 0.5%
- SNR: 85dB
- Soporta Tarjetas Micro SD de hasta 32GB

**Reproducir música vía Bluetooth:**

Una vez encendido el dispositivo, el indicador azul comenzará a parpadear, lo que indica que el dispositivo está listo para ser emparejado.

Desde el menú Bluetooth de su dispositivo móvil, busque nuevos dispositivos y seleccione "5767". Una vez vinculado, la luz azul permanecerá fija.

A partir de este momento, podrá controlar la música desde su dispositivo móvil, o bien desde el altavoz.

- Pulse para reproducir/pausar la música.
- Pulse + y - para cambiar de canción, y manténgalo pulsado para ajustar el volumen.

Nota: Pulse para cambiar de Modo.

**Reproducir música desde la tarjeta micro SD / Memoria USB:**

Introduzca la tarjeta micro SD / Memoria USB en la ranura correspondiente y la música comenzará a reproducirse de forma automática.

A partir de este momento, podrá controlar la música desde el altavoz.

Nota: No es necesario que el dispositivo esté conectado vía Bluetooth. Si previamente lo está, el altavoz cambiará al modo Tarjeta SD/USB de forma automática. Pulse para cambiar de modo.

**Entrada de Audio (Line in):**

Inserte el cable Jack en el puerto Jack del altavoz, e inserte el otro extremo en su reproductor mp3/ mp4 / teléfono móvil u otro dispositivo compatible para reproducir su música. Al conectar el cable, el dispositivo cambiará de modo de forma automática.

Pulse para silenciar la música y mantenga pulsado + o - para ajustar el volumen.

Nota: Pulse para cambiar de Modo

**Manos libres:**

Cuando el dispositivo se encuentra conectado vía Bluetooth, puede realizar la función de manos libres.

- Pulse para responder/colgar una llamada y manténgalo pulsado para rechazarla.
- Pulse play dos veces de forma consecutiva para volver a marcar la última llamada realizada.


Nota: Durante la llamada, podrá ajustar el volumen de la misma manteniendo pulsado + o -

**Solución de Problemas:**

Fallo	Solución
Imposible conectarse a otros dispositivos.	1. Revisar si el altavoz sigue en el proceso de búsqueda. Apáguelo y enciéndalo nuevamente. 2. Hay demasiados dispositivos Bluetooth alrededor que causan dificultad en la conexión. Por favor desconéctelos. 3. Asegúrese de que está en "modo asociación".
El sonido es bajo o distorsionado.	4. Revise el volumen de su dispositivo y ajústelo a un nivel adecuado. 5. Recargar la batería.
La música se detiene de vez en cuando.	6. Revise si la distancia efectiva de transmisión del altavoz es excesiva o si existe algún obstáculo entre el altavoz y el dispositivo Bluetooth.
El indicador LED se mantiene apagado.	7. Sugiere que el nivel de la batería es muy bajo, réinténte una vez cargado. 8. Encender de nuevo.

**Advertencias:**

1. No lo exponga a la lluvia o entornos mojados.
2. Evite caídas que le puedan generar daños serios.
3. No intente reparar la unidad por sí mismo, contacte con un especialista.
4. Para evitar riesgos, no se deshaga de él de manera inapropiada ya que posee una batería de litio integrada.
5. Limpíelo con un trapo seco.
6. No lo instale cerca de fuentes de calor o luz solar directa.
7. No inserte ningún objeto metálico en la unidad, existiría la posibilidad de un cortocircuito.
8. Mantenga fuera del alcance de los niños.




MADE IN PRC

El símbolo de referencia tanto en el producto como en su manual de usuario, indica que al final de la vida útil de los aparatos eléctricos y/o electrónicos, éstos deberán reciclarse por separado de sus residuos domésticos. Existen medios adecuados para recoger este tipo de material para su correcto reciclaje. Para obtener más información, póngase en contacto con la autoridad local.

Importado por:  
MIKTO CATAL IMPORTACIONES S.L. B04267225  
Ctra. De Huercal-Overa, s/n, 04640, Pulpí, Almería, Spain.


## BACK PART



**5767\_Speaker Clarmunt**  
**User Manual (Eng)**

It is recommended to read this user manual carefully and keep it for future reference.

**Product Overview:**



1. LED indicator
2. USB Port
3. Micro USB Port
4. : Play/Pause/Pick up/Hang up/Reject/Redial/ Scan the FM channels
5. +: Next track/Volume up/Change the FM channel
6. -: Previous track/Volume down/Change the FM channel
7. : ON/OFF/Mode
8. Jack connection: AUX function/ Line In
9. Micro SD Card Slot

**Specifications:**

- Bluetooth version 3.0
- Charge voltage: 5V
- Lithium battery 400mAh, 3.7V
- Frequency: 280Hz – 16KHz.
- Working time: Up to 3 hours.
- Working distance: Up to 10M
- Impedance: 4 ohms
- Power: 3W
- Distortion: less than 0.5%
- SNR: 85dB
- Support Micro SD Card up to 32GB

**Playing music via Bluetooth:**

When the speaker is powered on, the blue LED light will flash quickly, which indicates that the device is ready to be paired.

From the Bluetooth menu of your device, search for new devices and select "5767". Once paired, the blue LED light of the receiver will remain fixed.

From this moment, you can control the music from your mobile device, or from the speaker.

- Short press to play/pause the music.
- Short press + and - to change the song and long press to adjust the volume

Note: Short press to change mode

**Playing music by Micro SD Card / USB Flash drive:**

Insert the SD card / USB flash drive into the appropriate slot and the music will start playing automatically.

From this moment, you can control the music from the speaker.

Note: It is not necessary that the device is connected via Bluetooth. If it is previously, the speaker will switch to SD Card / USB mode automatically. Short press to change mode.

**Audio Input (Line in):**

Insert the Jack connection into the jack port of the speaker, and insert the other end into your mp3/mp4 player/mobile phone or other compatible device to play the music. When connecting the cable, the device will change mode automatically

Short press until you reach FM mode

Insert the micro USB cable into the micro USB port to work as an antenna. Short press to scan the FM channels. Once finished, short press + or - to change the channel, and long press to adjust the volume.

**Hands-free:**

When the device is connected via Bluetooth, you can use the hands-free function.

- Short press to pick up/hang up a call and long press to reject the incoming call.
- Short Press twice consecutively to redial the last outgoing phone number.

Note: During the call, you can adjust the volume of the call by keeping pressed + or -

**Charging:**


Insert the Micro USB connection into the Micro USB port on your device and connect the other end of the cable to your PC or AC/DC adaptor to charge the speaker. During the charging process, a red indicator light will remain on. When the charging process has finished, the indicator light will turn off. At the end of charging, do not forget to disconnect the cable.

**Troubleshooting:**

Fault	Solution
Unable to pair with other devices.	1. Check whether the speaker is still in the process of search or switch it off and on again. 2. There are too many Bluetooth devices in the proximity that cause difficulty in connection. Turn off other Bluetooth devices. 3. Make sure your device is in "Pairing Mode".
The sound is low or distorted.	4. Check the Bluetooth device volume and then adjust it to an appropriate level. 5. Recharge the battery.
Occasionally the music stops.	6. Check whether the speaker effective transmission range is exceeded or if there is an obstacle between the speaker and other Bluetooth devices.
The LED indicator does not light up.	7. The battery level is low, recharge the device. 8. Switch the speaker off and on again.

**Warnings:**

1. Do not expose this product to rain or damp conditions.
2. Prevent this item from falling as it could cause serious damage.
3. Do not dismantle, repair or modify this product by yourself, contact an authorized specialist.
4. In order to avoid any risk, do not dispose of this product inappropriately as there is a built-in Lithium battery.
5. Clean the speaker with a dry cloth.
6. Do not place this item near sources of heat or expose to direct sunlight.
7. Do not insert any metal objects into this device as there is a risk of causing a short circuit in the unit.
8. Keep out of reach of children.



MADE IN PRC

This symbol both in the product and its user manual indicates that at the end of the devices electrical life, it should be recycled separately from your household waste. There are adequate means to dispose of this material for proper recycling. For more information, contact your local authorities.

Imported by:  
MIKTO CATAL IMPORTACIONES S.L. B04267225  
Ctra. De Huercal-Overa, s/n, 04640, Pulpí, Almería, Spain.