

5150_PASTILLERO ZIPRIK

5150_Pastillero (Esp) Manual de instrucciones



Recomendamos que lea detenidamente este manual de instrucciones y lo conserve para futuras consultas.

AJUSTE DEL RELOJ

1. Retire el protector de la batería.
2. Pulse **H** para fijar la hora. Pulse **M** para ajustar.
3. Pulse **H** para fijar los minutos. Pulse **M** para ajustar.
4. Pulse **H** para fijar el mes. Pulse **M** para ajustar.
5. Pulse **H** para fijar el año. Pulse **M** para ajustar.
6. Pulse **H** dos veces para finalizar

MODO ALARMA (cuenta atrás)

En este modo, puede fijar una alarma que pondrá en marcha una cuenta atrás.

1. Pulse **ST/SP**.
2. Pulse **H** para ajustar la hora y **M** para ajustar los minutos.
3. Una vez finalizado, pulse el botón **ST/SP** para empezar la cuenta atrás.
4. Pulse **ST/SP** para pausar la alarma. Pulse de nuevo **ST/SP** para reanudarla.
5. Al llegar a cero, escuchará un sonido a modo de alarma (60 segundos de duración). Pulse cualquier botón para detenerla.
6. Pulse **H** y **M** al mismo tiempo para poner el contador a cero.
7. Mantenga pulsado el botón **H** si se quiere visualizar la hora.

MODO HORA

1. Pulse **H**, **M** y **ST/SP** al mismo tiempo para volver al modo hora.

MODO CRONÓMETRO

1. Pulse **ST/SP**.
2. Pulse **ST/SP** de nuevo para iniciar el temporizador.
3. Pulse **ST/SP** para pausar y reanudar.
4. Pulse **H** y **M** al mismo tiempo para poner el contador a cero.
5. Mantenga pulsado el botón **H** si se quiere visualizar la hora.

Notas:

- El tiempo máximo de la alarma y el cronómetro es de 19 horas y 59 minutos.
- No se pueden usar varias funciones al mismo tiempo. El cambiar de un modo a otro desactiva al anterior.
- El reloj debe ser ajustado cuando se reemplace la batería.

CE
MADE IN PRC



El símbolo de referencia tanto en el producto como en su manual de usuario, indica que al final de la vida útil de los aparatos eléctricos y/o electrónicos, éstos deberán reciclarse por separado de sus residuos domésticos.

Existen medios adecuados para recoger este tipo de material para su correcto reciclaje. Para obtener más información, póngase en contacto con la autoridad local.

Importado por: MKTO CATAL IMPORTACIONES S.L.
Ctra. De Huercaal-Overa, s/n, 04640, Pulpi, Almería, Spain.

5150_Pillbox (Eng) User Manual



It is recommended to read this user manual carefully and keep it for future reference.

CLOCK SET

1. Remove the battery stopper.
2. Press **H** button to set the hour. Press **M** button to adjust.
3. Press **H** button to set the minutes. Press **M** button to adjust.
4. Press **H** button to set the month. Press **M** button to adjust.
5. Press **H** button to set the year. Press **M** button to adjust.
6. Press **H** button twice to finish.

TIMER ALARM (countdown)

In this mode, it is possible to set an alarm that starts a countdown.

1. Press **ST/SP** button.
2. Press **H** button to set the hour and press **M** button to set the minutes.
3. When done, press **ST/SP** button to start the countdown.
4. Press **ST/SP** button once to pause. Press the **ST/SP** button again to continue counting down.
5. When it reaches zero, the alarm will sound with a loud beep (lasting 60 seconds). Press any button to stop the alarm.
6. Press **H** and **M** button at the same time to reset the timer to zero.
7. Hold down the **H** button to view the time.

TIME MODE

1. Press **H**, **M** and **ST/SP** button at the same time to show real time.

STOPWATCH (count up)

1. Press **ST/SP** button.
2. Press **ST/SP** button again to begin counting.
3. Press **ST/SP** button once to pause. Press the **ST/SP** button again to continue counting up.
4. Press **H** and **M** button at the same time to reset the timer to zero.
5. Hold down the **H** button to view the time.

Notes:

- Maximum Stopwatch and alarm time is 19 hours and 59 minutes.
- It is not possible to use various functions at the same time. Changing from one mode to another deactivates the previous.
- The clock should be adjusted when the batteries have been changed.

CE
MADE IN PRC



This symbol both in the product and its user manual indicates that at the end of the devices electrical life, it should be recycled separately from your household waste. There are adequate means to dispose of this material for proper recycling.

For more information, contact your local authorities.

Imported by: MKTO CATAL IMPORTACIONES S.L.
Ctra. De Huercaal-Overa, s/n, 04640, Pulpi, Almería, Spain.