

# 21020\_ALTAVOZ FLORENS


## FRONT PART

### 21020 - Altavoz Florens Manual de instrucciones (Esp)



Recomendamos que lea detenidamente este manual de instrucciones y lo conserve para futuras consultas.

#### Descripción del Producto:



1. Encendido/Apagado/Modo
2. Canción anterior
3. Pausa/Reproducción
4. Canción siguiente
5. Indicadores luminosos
6. Entrada Micro USB
7. Ranura Micro SD
8. Control de volumen

#### Especificaciones:

- Versión Bluetooth 5.0
- Voltaje de carga: 5V
- Batería de Litio 500mAh, 3.7V
- Tiempo en funcionamiento máximo: 2-3h
- Distancia de funcionamiento: Hasta 10 metros
- Frecuencia: 200Hz-20KHz
- Impedancia: 4 Ohms
- Potencia: 3W
- THD: menos del 2%
- SNR: >75dB
- Soporta Tarjetas Micro SD de hasta 64GB

#### Funcionamiento:

Mantenga pulsado el botón de encendido. El indicador luminoso de color azul comenzará a parpadear, lo que indica que el dispositivo está listo para ser emparejado.  
Mantenga pulsado el botón para apagar el altavoz.

#### Reproducir música via Bluetooth:

Desde el menú Bluetooth de su dispositivo, busque nuevos dispositivos y seleccione "21020" para asociarlo a su teléfono. Una vez asociados correctamente, oír un sonido de confirmación y el indicador luminoso permanecerá fijo.

#### Reproducir música desde la tarjeta micro SD:

Inserte una tarjeta Micro SD en la ranura correspondiente y el altavoz reproducirá automáticamente la música de la misma.

#### Radio FM:

Inserte el cable incluido en el puerto Micro USB del altavoz, el cual funcionará como antena. Pulse **▶▶** y el altavoz buscará automáticamente las emisoras de radio disponibles. Pulse **◀◀** o **▶▶** para cambiar de emisora.

#### Carga:

Conecte el altavoz a una fuente de alimentación adecuada utilizando el cable suministrado.

Durante el proceso de carga, un indicador luminoso en color rojo permanecerá encendido. Cuando el proceso de carga haya finalizado, el indicador se apagará.

#### Solución de problemas:

FaBo	Solución
Imposible conectarse a otros dispositivos.	1. Revisar si el altavoz sigue en el proceso de búsqueda. Apáguelo y enciéndalo nuevamente. 2. Hay demasiados dispositivos Bluetooth alrededor que causan dificultad en la conexión. Por favor desconéctelos. 3. Asegúrese de que está en "modo asociación".
El sonido es bajo o distorsionado.	4. Revise el volumen de su dispositivo y ajústelo a un nivel adecuado. 5. Recargar la batería.
La música se detiene de vez en cuando.	6. Revise si la distancia efectiva de transmisión del altavoz es excedida o si existe algún obstáculo entre el altavoz y el dispositivo Bluetooth.

#### Advertencias:

1. No lo exponga a la lluvia o entornos mojados.
2. Evite caídas que le puedan generar daños serios.
3. No intente reparar la unidad por sí mismo, contacte con un especialista.
4. Para evitar riesgos, no se deshaga de él de manera inapropiada ya que posee una batería de litio integrada.
5. Limpíelo con un trapo seco.
6. No lo instale cerca de fuentes de calor o luz solar directa.
7. No inserte ningún objeto metálico en la unidad, existiría la posibilidad de un cortocircuito.
8. Mantenga fuera del alcance de los niños.



El símbolo de referencia tanto en el producto como en su manual de usuario, indica que al final de la vida útil de los aparatos eléctricos y/o electrónicos, éstos deberán reciclarse por separado de sus residuos domésticos. Existen medios adecuados para recoger este tipo de material para su correcto reciclaje.  
Para obtener más información, póngase en contacto con la autoridad local.

Por la presente, Mtko Catal Importaciones S.L. declara que este equipo radioeléctrico es conforme con la Directiva 2014/53/EU. El texto completo de la declaración UE de conformidad está disponible en: [www.mtko.es](http://www.mtko.es) (búsque por referencia).

MKTO CATAL IMPORTACIONES S.L. B04267225  
Ctra. de Huércal-Overa, s/n, 04640, Púlp, Almería, Spain.

## BACK PART

### 21020 - Speaker Florens User Manual (Eng)



It is recommended to read this user manual carefully and keep it for future reference.

#### Product Overview:



1. Power On/Off/Mode
2. Previous track
3. Pause/Play
4. Next track
5. Indicator lights
6. Micro USB Input
7. Micro SD Slot
8. Volume control

#### Specifications:

- Bluetooth version 5.0
- Charging voltage: 5V
- Lithium battery 500mAh 3.7V
- Max. Working Time: Up to 2-3h
- Operating distance: up to 10 meters
- Frequency: 200Hz-20KHz
- Impedance: 4 Ohms
- Output power: 3W
- THD: less than 2%
- SNR: >75dB
- Support Micro SD cards up to 64GB

#### Operation:

Press the button ON/MODE to power on the speaker. The indicator light will start flashing to indicate that the device is ready to be paired.

Keep pressed the button to power off the speaker.

#### Playing Music via Bluetooth:

From the Bluetooth menu of your device, search for new devices and select "21020" to pair. Once they are paired successfully, you will hear a notification sound and the indicator light will stay on.

#### Playing Music via Micro SD Card:

When u insert a micro SD card into the micro SD card, the music will automatically start playing.

#### FM Radio:

Connect the included cable into the Micro USB port to work as an antenna. Short press **▶▶** and the speaker will automatically search for radio channels. Short press **◀◀** or **▶▶** to change the channel.

#### Charging:

Connect the device to a suitable power supply using the supplied cable.

During charging, the red indicator light will stay on. When the speaker is fully charged the indicator light will turn off.

#### Troubleshooting:

Fault	Solution
Unable to pair with other devices.	1. Check whether the speaker is still in the process of search or switch it off and on again. 2. There are too many Bluetooth devices in the proximity that cause difficulty in connection. Turn off other Bluetooth devices. 3. Make sure your device is in "Pairing Mode".
The sound is low or distorted.	4. Check the Bluetooth device volume and then adjust it to an appropriate level. 5. Recharge the battery.
Occasionally the music stops.	6. Check whether the speaker effective transmission range is exceeded or if there is an obstacle between the speaker and other Bluetooth devices.

#### Warnings:

1. Do not expose this product to rain or damp conditions.
2. Prevent this item from falling as it could cause serious damage.
3. Do not dismantle, repair or modify this product by yourself, contact an authorized specialist.
4. In order to avoid any risk, do not dispose of this product appropriately as there is a built-in Lithium battery.
5. Clean the speaker with a dry cloth.
6. Do not place this item near sources of heat or expose to direct sunlight.
7. Do not insert any metal objects into this device as there is a risk of causing a short circuit in the unit.
8. Keep out of reach of children.



This symbol both in the product and its user manual indicates that at the end of the devices electrical life, it should be recycled separately from your household waste. There are adequate means to dispose of this material for proper recycling. For more information, contact your local authorities.

Hereby, Mtko Catal Importaciones S.L. declares that this radio equipment is in compliance with Directive 2014/53/EU. The full text of the UE declaration of conformity is available at: [www.mtko.es](http://www.mtko.es) (search on reference).

MKTO CATAL IMPORTACIONES S.L. B04267225  
Ctra. de Huércal-Overa, s/n, 04640, Púlp, Almería, Spain.