

21024_RECORTADORA PELO JAMET


FRONT PART

21024 - Recortadora Pelo Jamet Manual de instrucciones (Esp)



Recomendamos que lea detenidamente este manual de instrucciones y lo conserve para futuras consultas.

Descripción del Producto:



Especificaciones:

- Voltaje: 1.5V \equiv Pila AA (no incluida)

Funcionamiento:

Extraiga la tapa del compartimento inferior y coloque una pila AA respetando las indicaciones de polaridad.

Cierre el compartimento y pulse el interruptor para encender/apagar el dispositivo.

Con el aparato apagado, coloque el peine adecuado para realizar el corte a la longitud deseada.

Advertencias:

1. El aparato no está destinado a ser usado por niños o personas con capacidades físicas, sensoriales o mentales reducidas, o con falta de experiencia y conocimiento, a menos que dichas personas reciban una supervisión o instrucciones necesarias para el funcionamiento del aparato. Mantener alejado de los niños.
2. No lo exponga a la lluvia o entornos mojados. Mantener el aparato seco.
3. Evite caídas que le puedan generar daños serios.
4. No intente reparar la unidad por sí mismo, contacte con un especialista.
5. Para evitar riesgos, no se deshaga de él de manera inapropiada.
6. Limpelo con un trapo seco.
7. No lo instale cerca de fuentes de calor.
8. No inserte ningún objeto metálico en la unidad, existiría la posibilidad de un cortocircuito.



El símbolo de referencia tanto en el producto como en su manual de usuario, indica que al final de la vida útil de los aparatos eléctricos y/o electrónicos, éstos deberán reciclarse por separado de sus residuos domésticos. Existen medios adecuados para recoger este tipo de material para su correcto reciclaje. Para obtener más información, póngase en contacto con la autoridad local.

MKTO CATAL IMPORTACIONES S.L. B04267225
Ctra. de Huércal-Overa, s/n, 04640, Pulpí, Almería, Spain.

BACK PART

21024 - Hair Trimmer Jamet User manual (Eng)



It is recommended to read this user manual carefully and keep it for future reference.

Product overview:



Specifications:

- Voltage: 1.5V \equiv AA battery (not included)

Operation:

Remove the cover of the lower compartment and insert an AA battery, respecting the polarity indications.

Close the compartment and press the switch to turn the device on/off.

With the device turned off, place the appropriate comb to make the cut at the desired length.

Warnings:

1. The appliance is not intended for use by children or persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless such persons are given supervision or instructions necessary for the operation of the appliance. Keep away from children.
2. Do not expose it to rain or wet environments. Keep the device dry.
3. Avoid falls that could cause serious damage.
4. Do not attempt to repair the unit yourself, contact a specialist.
5. To avoid risks, do not dispose of it inappropriately.
6. Wipe it with a dry cloth.
7. Do not install near heat sources.
8. Do not insert any metal objects into the unit, there is a possibility of a short circuit.



This symbol both in the product and its user manual indicates that at the end of the devices electrical life, it should be recycled separately from your household waste. There are adequate means to dispose of this material for proper recycling. For more information, contact your local authorities.

MKTO CATAL IMPORTACIONES S.L. B04267225
Ctra. de Huércal-Overa, s/n, 04640, Pulpí, Almería, Spain.