

5279_SET VIAJE YASTIN - 85 x 65 mm

INSTRUCCIONES DE USO ES

La cerradura está ajustada por defecto para abrir con la combinación 000. Puede dejar este código o crear uno nuevo siguiendo estos pasos:

1. Con el cable de cierre no introducido en el candado, mantenga presionada la pestaña de apertura y gire las ruedas hasta ajustar la combinación deseada.

Nota: Puede notar un poco de resistencia al girar las ruedas.

2. Suelte la pestaña de apertura e introduzca el cable del cierre.

A continuación desordene los números. El candado se debería mantener cerrado.

3. Cuando quiera abrir el candado, gire las ruedas hasta la combinación guardada.

YASTIN



YASTIN



ITEM 5279

USER INSTRUCTIONS EN

The lock is set by the manufacturer to open at 000. You can keep this combination or set a new one by following these steps:

1. Hold down the button on the top of the lock, without the end of the cable being inserted and rotate the numbers to set your desired code.

Note: You may feel a slight resistance when turning each wheel.

2. Release the button and insert the cable end into the hole at the top of the lock. Then rearrange the numbers to close the lock.

3. When you want to open the lock, turn the wheels to the code you originally set up.