

# 5771\_CAMARA 360° RIBBEN

## FRONT PART

### 5771\_Cámara 360° Ribben Manual de instrucciones (Esp)




Recomendamos que lea detenidamente este manual de instrucciones y lo conserve para futuras consultas.

#### Especificaciones:

- Resolución de imagen: 5M
- Formato de imagen: JPG
- Resolución de vídeo: 2048x1024 / 1920x960
- Formato de vídeo: MP4
- Compresión de vídeo: H.264
- Grado de protección: IP68
- Chipset: VIA 3881M
- Sensor: PixArt 5230
- Ángulo visual: 220°
- Requisitos mínimos: Android 5.1 y función OTG

#### Funcionamiento:


Descargue e instale "VPai" desde Google Playstore. También puede hacerlo desde el código QR que se muestra más abajo.



Conecte la cámara a su dispositivo móvil y acceda a la aplicación. Tras unos segundos, podrá visualizar la imagen de la cámara en su dispositivo y podrá hacer uso de las distintas funciones.

#### Funciones principales:

Este dispositivo le permite tomar fotos y grabar vídeos desde diversas perspectivas. Para seleccionárselas, pulse la opción que se muestra en el lado izquierdo de la pantalla hasta llegar a la opción deseada.



Si desea activar el temporizador, seleccione la opción que se muestra en la parte superior izquierda de la pantalla, y elija entre 5 y 10 segundos.



Para cambiar la resolución de vídeo, acceda a los ajustes de la aplicación.



Si desea variar el enfoque de la cámara, mantenga activada la opción "Tocar" y deslice el dedo por la pantalla en el sentido deseado.


También puede activar o desactivar la opción giroscopio. Esta opción es aconsejable para Realidad Virtual y vídeos 360.



Para acceder al modo "Time Lapse" seleccione la opción Encogimiento. Esta opción le permite grabar un vídeo en tiempo real que será reproducirlo de forma rápida. Cada 30 segundos de tiempo real, equivalen a 1 segundo en el modo "Time Lapse". De esta forma, podrá almacenar un periodo de grabación extenso en el tiempo, en un vídeo reducido.



Desde la Galería de la aplicación, podrá editar el estilo de las fotos y vídeos, así como compartírselos a través de servicios de mensajería y redes sociales.



Además, podrá emitir vídeos en directo a través de diversas plataformas.



#### Advertencias:

1. No la exponga a la lluvia o entornos mojados.
2. No exponga la unidad a objetos con fuertes campos magnéticos, tales como imanes o motores eléctricos.
3. Evite caídas que le puedan generar serios daños.
4. No intente reparar la unidad por su propia cuenta, contacte con un especialista.
5. Para evitar riesgos, no se deshaga de él de manera inapropiada.
6. Limpíela con un trapo seco.
7. No la instale cerca de fuentes de calor o luz solar directa.
8. No inserte ningún objeto metálico en la unidad, existiría la posibilidad de un cortocircuito.
9. Mantenga el producto fuera del alcance de los niños.



El símbolo de referencia tanto en el producto como en su manual de usuario, indica que al final de la vida útil de los aparatos eléctricos y/o electrónicos, éstos deberán reciclarse por separado de sus residuos domésticos. Existen medios adecuados para recoger este tipo de material para su correcto reciclaje. Para obtener más información, póngase en contacto con la autoridad local.

Importado por:  
MKTO CATAL IMPORTACIONES S.L. B04267225  
Ctra. De Huerca-Overa, s/n, 04640, Pulpi, Almería, Spain.

## BACK PART

### 5771\_360° Camera Ribben User Manual (Eng)




It is recommended to read this user manual carefully and keep it for future reference.

#### Specifications:

- Image resolution: 5M
- Image format: JPG
- Video resolution: 2048x1024 / 1920x960
- Video format: MP4
- Video Encoder: H.264
- Degree of protection: IP68
- Chipset: VIA 3881M
- Sensor: PixArt 5230
- 220° Angle lens
- Minimum requirements: Android 5.1 and OTG function

#### Operation:


Download and install "VPai" from Google Playstore. Also available from the QR Code shown below.



Connect the camera to your mobile device and access the application. After a few seconds, you can view the image of the camera on your device and you can make use of the different functions.

#### Main Functions:

This device allows you to take photos and record videos from different perspectives. Press the option shown on the left side of the screen to select the required option.



To activate the timer, select the option shown on the top left of the screen and choose either 5 or 10 seconds.



To change the video resolution, go to settings on the application.



To focus the camera, keep the "Touch" option activated and slide your finger across the screen in either direction.


You can also activate or deactivate the gyroscope option. This option is advisable for Virtual Reality and 360 videos.



To access the "Time Lapse" mode select the Shrink option. This option allows you to record a video in real time that will be played at fast speed. Every 30 seconds of real time is equivalent to 1 second in the "Time Lapse" mode. In this way, you can store a recording taken over a long period of time, in a reduced size video.



From the App Gallery, you can edit the style of the photos and videos, as well as share them through messaging services and social networks.



You can also broadcast live videos through various platforms.



#### Warnings:

1. Do not expose this product to the rain or damp conditions.
2. Do not expose the unit to strong magnetic objects, such as magnet, and electrical motors.
3. Prevent this item from falling as it could result in serious damage.
4. Do not dismantle, repair or modify this product by yourself, contact an authorized specialist.
5. In order to avoid any risk, do not dispose of this product inappropriately.
6. Clean the camera with a dry cloth.
7. Do not place this item near sources of heat or expose to direct sunlight.
8. Do not insert any metal object into this device as there is a risk of causing a short circuit in the unit.
9. Keep the product out of children's reach.



This symbol both in the product and its user manual indicates that at the end of the devices electrical life, it should be recycled separately from your household waste. There are adequate means to dispose of this material for proper recycling. For more information, contact your local authorities.

Imported by:  
MKTO CATAL IMPORTACIONES S.L. B04267225  
Ctra. De Huerca-Overa, s/n, 04640, Pulpi, Almería, Spain.