

20254_ALTAVOZ CARGADOR CEDRIC

FRONT PART

20254-Altavoz Cargador Cedric Manual de instrucciones (Esp)



Recomendamos que lea detenidamente este manual de instrucciones y lo conserve para futuras consultas.

Descripción del Producto:



Especificaciones:

Altavoz

- Versión Bluetooth 5.3
- Voltaje de Carga: 5V
- Batería de Litio 1.200mAh, 3.7V
- Tiempo en funcionamiento: 4-5 h
- Distancia de funcionamiento: Hasta 10 metros
- Frecuencia: 100Hz-20KHz
- Impedancia: 4ohms
- Potencia: 5W
- THD: menos del 10%
- SNR: 80dB

Cargador Inalámbrico

- Entrada: 5-9V 2-2.2A
- Salida Carga Inalámbrica: 5-9V 1-1.67A, 5-15W
- Apto para todos los dispositivos móviles con tecnología Qi.

Carga:

Utilice para la carga el cable suministrado. Conecte el cable USB a la fuente de alimentación adecuada. Conecte el otro extremo del cable en el puerto de carga del dispositivo.

Durante el proceso de carga, el indicador luminoso en color rojo permanecerá encendido. Cuando el proceso de carga haya finalizado, el indicador LED de la parte trasera se apagará.

Funcionamiento del cargador inalámbrico:

1. Conecte el cable Tipo C en el puerto del dispositivo y el otro extremo en la fuente de alimentación adecuada

2. Coloque su dispositivo compatible con carga Qi sobre el cargador. Asegúrese de que su dispositivo está colocado en el centro del cargador.
3. Si la carga se produce correctamente, el indicador luminoso se mostrará en color verde.

Nota: Para garantizar el funcionamiento del cargador es recomendable retirar la carcasa protectora de su dispositivo móvil.

Funcionamiento del altavoz:

Mantenga pulsado el botón On/Off para encender el altavoz. La luz de color azul comenzará a parpadear, lo que indica que el dispositivo está listo para ser emparejado.

Desde el menú Bluetooth de su dispositivo, busque nuevos dispositivos y seleccione "20254" para asociarlo a su teléfono. Una vez asociados correctamente, oír un sonido de confirmación y la luz permanecerá fija. Durante la reproducción de música, el indicador parpadeará lentamente

Al finalizar, mantenga pulsado el botón para apagar el altavoz.

Solución de problemas

Fallo	Solución
Imposible conectarse a otros dispositivos.	1. Revise si el altavoz sigue en el proceso de búsqueda. Apáguelo y enciéndalo nuevamente. 2. Hay demasiados dispositivos Bluetooth alrededor que causan dificultad en la conexión. Por favor desconéctelos. 3. Asegúrese de que está en "modo asociación"
El sonido es bajo o distorsionado.	4. Revise el volumen de su dispositivo y ajústelo a un nivel adecuado. 5. Recargar la batería.
La música se detiene de vez en cuando.	6. Revise si la distancia efectiva de transmisión del altavoz es excesiva o si existe algún obstáculo entre el altavoz y el dispositivo Bluetooth.

Advertencias:

1. No lo exponga a la lluvia o entornos mojados.
2. Evite caídas que le puedan generar daños serios.
3. No intente reparar la unidad por sí mismo, contacte con un especialista.
4. Para evitar riesgos, no se deshaga de él de manera inapropiada ya que posee una batería de litio integrada.
5. Limpielo con un trapo seco.
6. No lo instale cerca de fuentes de calor o luz solar directa.
7. No inserte ningún objeto metálico en la unidad, existiría la posibilidad de un cortocircuito.
8. Para evitar riesgos durante el proceso de carga, no coloque ningún objeto metálico entre el cargador y el dispositivo móvil.
9. No utilizar dispositivos móviles con carcasa metálica.



El símbolo de referencia tanto en el producto como en su manual de usuario, indica que al final de la vida útil de los aparatos eléctricos y/o electrónicos, éstos deberán reciclarse por separado de sus residuos domésticos. Existen medios adecuados para recoger este tipo de material para su correcto reciclaje. Para obtener más información, póngase en contacto con la autoridad local.

Por la presente, Mtko Catal Importaciones S.L. declara que este equipo radioeléctrico es conforme con la Directiva 2014/53/EU. El texto completo de la declaración UE de conformidad está disponible en: www.makilo.es (busque por referencias).

MKTO CATAL IMPORTACIONES S.L. B04267225
Ctra. De Huerca-Overa, s/n. 04640, Pulpí, Almería, Spain.

BACK PART

20254_Charger Speaker Cedric User manual (Eng)



It is recommended to read this user manual carefully and keep it for future reference.

Product overview:



Specifications:

- Bluetooth Version 5.3
- Charging voltage: 5V
- Lithium battery 1.200mAh 3.7V
- Working Time: 4-5 h
- Operating distance: up to 10 meters
- Frequency: 100Hz-26KHz
- Impedance: 4ohms
- Power output: 5W
- THD: less than 10%
- SNR: 80dB
- Suitable for all mobile devices with Qi technology

Wireless charger:

- Input: 5-9V 2-2.2A
- Wireless Output: 5-9V 1-1.67A, 5-15W
- Suitable for all mobile devices with Qi technology

Charging:

Use the cable provided for charging. Connect the USB to the suitable power supply and connect the other end of the cable into the device charging port.

During charging, the red indicator light will stay on. When the speaker is fully charged the indicator light at the back will turn off.

Wireless charger operation:

1. Connect the Type C cable to the Type C port on the device and the other end of the cable into a USB port or into a USB AC adapter.

2. Place your Qi compatible device on top of the wireless charger, ensuring that it is face up and centrally positioned.
3. When it is charging correctly the green indicators light will stay on.

Note: If your phone has a protective case you may need to remove it for a successful connection.

Speaker operation:

Long press the On/Off button to power on the speaker. The blue indicator light will start flashing to indicate that the device is ready to be paired.

From the Bluetooth menu of your device, search for new devices and select "20254" to pair. Once they are paired successfully, you will hear a notification sound and the lights will stay on. During music playback, the indicator will flash slowly.

Once finished using, long press button to power off the speaker.

Troubleshooting

Fault	Solution
Unable to pair up with other devices.	1. Check whether the speaker is still on the process of search or switch it off and on again. 2. There are too many Bluetooth devices in the proximity that cause difficulty in connection. Turn off other Bluetooth devices. 3. Make sure your earphone is in "Pairing Mode".
The sound is low or distorted.	4. Check the Bluetooth device's volume and then adjust it to an appropriate level. 5. Recharge the battery.
Occasionally the music stops.	6. Check whether the speaker effective transmission range is exceeded or if there is an obstacle standing between the speaker and other Bluetooth devices.

Warnings:

1. Do not expose this product to rain or damp conditions.
2. Prevent this item from falling as it could cause serious damage.
3. Do not dismantle, repair or modify this product by yourself, contact an authorized specialist.
4. In order to avoid any risk, do not dispose of this product inappropriately or throw it into the fire as there is a built-in Lithium battery.
5. Clean it with a dry cloth.
6. Do not place this item near sources of heat or expose to direct sunlight.
7. Do not insert any metal objects into this device as there is a risk of causing a short circuit in the unit.
8. To avoid risk, do not place any metal objects between the charger and the mobile device during the charging process.
9. Do not use mobile devices with a metal case.



This symbol both in the product and its user manual indicates that at the end of the devices electrical life, it should be recycled separately from your household waste. There are adequate means to dispose of this material for proper recycling. For more information, contact your local authorities.

Hereby, Mtko Catal Importaciones S.L. declares that this radio equipment is in compliance with Directive 2014/53/EU. The full text of the UE declaration of conformity is available at: www.makilo.es (search on reference).

MKTO CATAL IMPORTACIONES S.L. B04267225
Ctra. De Huerca-Overa, s/n. 04640, Pulpí, Almería, Spain.