

20875_ESTACIÓN METEOROLÓGICA ROAMER

FRONT PART

20875 - Estación Meteorológica Roamer Manual de instrucciones (Esp)



Recomendamos que lea detenidamente este manual de instrucciones y lo conserve para futuras consultas.

Descripción del Producto:



Especificaciones:

- Rango de temperatura (0-50°C, 32-122°F). Precisión +/-1°C
- Calendario
- Alarma
- Rango de humedad (20-95%). Precisión +/- 5%
- Formato hora 12/24h.
- Temperatura y humedad máxima y mínima.
- Icono de tiempo.

Funcionamiento:

Quite la tapa trasera del dispositivo e introduzca una pila AAA.

Configuración :

Pulse MODE hasta mostrar en pantalla el valor a configurar (Hora-Alarma-Fecha)

Mantenga pulsado el boton SET durante 3 segundos para entrar en el modo configuración.

Los dígitos comenzaran a parpadear. A continuación, pulse UP/ DOWN para ajustarlos y de nuevo SET para fijar los valores deseados.

Pulse MODE o espere 20 segundos para finalizar la configuración.

Alarma:

Desde la pantalla de alarma, pulse UP para activar/desactivar la misma. El símbolo ☁ se mostrará cuando esté activa.

Continúe pulsando para activar el aviso horario, el cuál se mostrará en pantalla ☁ cuando esté activo.

Puede activar ambos independientemente.

Una vez suene la alarma, pulse la tecla DOWN para retrasarla 4 minutos(máximo 4 veces) o cualquier otra tecla para desactivarla.

Temperatura y humedad máxima/mínima:

Desde la pantalla horaria, pulse UP para mostrar los valores máximos de temperatura y humedad máxima registrada. Pulse nuevamente para visualizar los valores mínimos alcanzados.

Pulse el botón SET para cambiar la unidad de medición de la temperatura (°C - °F)

La estación meteorológica muestra una representación gráfica del tiempo actual.

Advertencias:

1. Para uso interior: No lo exponga a la lluvia o entornos mojados.
2. Evite caídas que le puedan generar daños serios.
3. No intente reparar la unidad por sí mismo, contacte con un especialista.
4. Para evitar riesgos, no se deshaga de él de manera inapropiada.
5. Limpíelo con un trapo seco.
6. No lo instale cerca de fuentes de calor o luz solar directa.
7. No inserte ningún objeto metálico en la unidad, existiría la posibilidad de un cortocircuito.
8. Mantenga fuera del alcance de los niños.



El símbolo de referencia tanto en el producto como en su manual de usuario, indica que al final de la vida útil de los aparatos eléctricos y electrónicos, estos deberán reciclarse por separado de sus residuos domésticos. Existen medios adecuados para recoger este tipo de material para su correcto reciclaje. Para obtener más información, póngase en contacto con la autoridad local. Antes de entregar los RAEE se deben extraer las pilas.

CE
FABRICADO EN PRC

MKTO CATAL IMPORTACIONES S.L. B04267225
Ctra. de Huércal-Overa, s/n, 04640, Pulpi, Almería, Spain.

BACK PART

20875 - Weather Station Roamer User manual (Eng)



It is recommended to read this user manual carefully and keep it for future reference.

Product overview:



Specificacions:

- Temperature range (0-50°C, 32-122°F). Accuracy +/- 1°C.
- Calendar
- Alarm
- Humidity range (20-95%). Accuracy +/- 5%.
- 12/24h format.
- Max/Min temperature and humidity.
- Weather icons.

Operation:

Remove the lid of the battery compartment and insert one AAA battery.

Configuration:

Press MODE until the value to be configured is shown on the screen (Time-Alarm-Date)

Press and hold the SET button for 3 seconds to enter configuration mode.

The digits will start flashing. Then press UP/DOWN to adjust them and SET again to set the desired values.

Press MODE or wait 20 seconds to finish setting.

Alarm:

From the alarm screen, press UP to activate/deactivate the alarm. The symbol ☁ will be displayed when active.

Continue pressing to activate the hourly warning, which will be displayed on the screen ☁ when active.

You can activate both independently.

Once the alarm sounds, press the DOWN key to delay it for 4 minutes (maximum 4 times) or any other key to deactivate it.

Temperature and humidity maximum/minimum:

From the time display, press UP to display the maximum recorded temperature and humidity values. Press again to view the minimum values reached.

Press the SET button to change the temperature measurement unit (°C - °F)

The weather station displays a graphic representation of the current weather

Warnings:

1. For interior use: Do not expose this product to rain or damp conditions.
2. Prevent this item from falling as it could cause serious damage.
3. Do not dismantle, repair or modify this product by yourself, contact an authorized specialist.
4. In order to avoid any risk, do not dispose of this product inappropriately.
5. Clean it with a dry cloth.
6. Do not place this item near sources of heat or expose to direct sunlight.
7. Do not insert any metal objects into this device as there is a risk of causing a short circuit in the unit.
8. Keep out of reach of children



This symbol both in the product and its user manual indicates that at the end of the devices electrical life, it should be recycled separately from your household waste. There are adequate means to dispose of this material for proper recycling. For more information, contact your local authorities. Before disposing the WEEE, please remove the batteries.

CE
MADE IN PRC

MKTO CATAL IMPORTACIONES S.L. B04267225
Ctra. de Huércal-Overa, s/n, 04640, Pulpi, Almería, Spain.