



21243_ANEMÓMETRO BALEST

FRONT PART

<p>21243_Anemómetro Balest Manual de instrucciones (Esp)</p>  <p>Recomendamos que lea detenidamente este manual de instrucciones y lo conserve para futuras consultas.</p>	<p>Descripción del producto:</p>  <p>Funciones:</p> <ol style="list-style-type: none"> Medición de temperatura y velocidad del aire Medición de la velocidad del aire máxima, promedio y actual Selección de unidad de temperatura °C/°F Cinco unidades de velocidad del aire: M/s, Km/h, ft/min, knots, mph Escala de Beaufort Pantalla retroiluminada Apagado manual/automático Indicación de sensación térmica Indicación de batería baja 	<p>Display LCD:</p>  <p>Funcionamiento:</p> <ol style="list-style-type: none"> Encienda: Presione el botón "MODE" para 2 segundos para encender la unidad. LCD will display Air velocity, temperature and battery icon. LCD backlight will last for 12 seconds. Set unit of air velocity and measuring mode: Press "MODE" button more than 3 seconds until "m/s" starts to blink. Press "SET" button to select desired air velocity unit. To confirm the unit, press "MODE" button. For setting MAX/AVG/CU mode, press "SET" button again and again until CU/MAX/AVG blink, then press "MODE" button to confirm. Measurement: When the wind vane (impeller) turns, LCD will instant display wind speed, temperature and beaufort scale. When temperature below 0 °C, "WIND CHIL" will be shown on the LCD. Turn off: Press "MODE" + "SET" buttons at the same time to turn off the unit. Auto power shut off: The unit will be shut off without any operation for 14 minutes. Change battery: When the symbol "—" shown on the LCD, please change the battery. 	<p>3. Set temperature unit: Temperature switch key (°C/F) conceal in the rear cabinet, please use a little push-pin to press the key for (°C/F) conversion.</p> <p>4. Backlight display: The backlight will be activated for 12 seconds by press any key.</p> <p>5. Measurement: When the wind vane (impeller) turns, LCD will instant display wind speed, temperature and beaufort scale. When temperature below 0 °C, "WIND CHIL" will be shown on the LCD.</p> <p>6. Turn off: Press "MODE" + "SET" buttons at the same time to turn off the unit.</p> <p>7. Auto power shut off: The unit will be shut off without any operation for 14 minutes.</p> <p>8. Change battery: When the symbol "—" shown on the LCD, please change the battery.</p>	<p>Especificaciones:</p> <table border="1"> <thead> <tr> <th colspan="5">A. Air velocity</th> </tr> <tr> <th>Unit</th> <th>Range</th> <th>Resolution</th> <th>Threshold</th> <th>Accuracy</th> </tr> </thead> <tbody> <tr> <td>M/s</td> <td>0~30</td> <td>0.1</td> <td>0.1</td> <td rowspan="4">± 5%</td> </tr> <tr> <td>Ft/min</td> <td>0~5860</td> <td>19</td> <td>39</td> </tr> <tr> <td>Knots</td> <td>0~55</td> <td>0.2</td> <td>0.1</td> </tr> <tr> <td>Km/hr</td> <td>0~90</td> <td>0.3</td> <td>0.3</td> </tr> <tr> <td>Mph</td> <td>0~65</td> <td>0.2</td> <td>0.2</td> </tr> </tbody> </table> <table border="1"> <thead> <tr> <th colspan="4">B. Temperature</th> </tr> <tr> <th>Unit</th> <th>Range</th> <th>Resolution</th> <th>Accuracy</th> </tr> </thead> <tbody> <tr> <td>°C</td> <td>-10°C~+45°C</td> <td>0.2</td> <td>± 2°C</td> </tr> <tr> <td>°F</td> <td>-14°F~+113°F</td> <td>0.36</td> <td>± 3.6°C</td> </tr> </tbody> </table> <table border="1"> <thead> <tr> <th>Battery</th> <th>CR2032 3.0V (Included)</th> </tr> </thead> <tbody> <tr> <td>Thermometer</td> <td>NTC Thermometer</td> </tr> <tr> <td>Operating temperature</td> <td>-10°C~+45°C(4°F~113°F)</td> </tr> <tr> <td>Operating humidity</td> <td>Less than 90% RH</td> </tr> <tr> <td>Store temperature</td> <td>-40°C~+60°C(-40°F~140°F)</td> </tr> <tr> <td>Current consumption</td> <td>Approx. 3mA</td> </tr> </tbody> </table>	A. Air velocity					Unit	Range	Resolution	Threshold	Accuracy	M/s	0~30	0.1	0.1	± 5%	Ft/min	0~5860	19	39	Knots	0~55	0.2	0.1	Km/hr	0~90	0.3	0.3	Mph	0~65	0.2	0.2	B. Temperature				Unit	Range	Resolution	Accuracy	°C	-10°C~+45°C	0.2	± 2°C	°F	-14°F~+113°F	0.36	± 3.6°C	Battery	CR2032 3.0V (Included)	Thermometer	NTC Thermometer	Operating temperature	-10°C~+45°C(4°F~113°F)	Operating humidity	Less than 90% RH	Store temperature	-40°C~+60°C(-40°F~140°F)	Current consumption	Approx. 3mA	<p>Advertencias:</p> <ol style="list-style-type: none"> No lo exponga a la lluvia o entornos mojados. Evite caídas que le puedan generar daños serios. No intente reparar la unidad por sí mismo, contacte con un especialista. Para evitar riesgos, no se deshaga de él de manera inapropiada. Limpíelo con un trapo seco. No lo instale cerca de fuentes de calor o luz solar directa. No inserte ningún objeto metálico en la unidad, existiría la posibilidad de un cortocircuito. Mantenga fuera del alcance de los niños. <p>CE MADE IN PRC</p> <p> El símbolo de referencia tanto en el producto como en su manual de usuario, indica que al final de la vida útil de los aparatos eléctricos y/o electrónicos, éstos deberán reciclarse por separado de sus residuos domésticos. Existen medios adecuados para recoger este tipo de material para su correcto reciclaje.</p> <p>Para obtener más información, póngase en contacto con la autoridad local.</p> <p>Por la presente, Miko Catal Importaciones S.L., declara que este equipo radioeléctrico es conforme con la Directiva 2014/53/EU. El texto completo de la declaración UE de conformidad está disponible en: www.makito.es (busque por referencia).</p> <p>MIKO CATAL IMPORTACIONES S.L., B04267225 Ctra. de Huércal-Overa, s/n, 04640, Pulpi, Almería, Spain.</p>
A. Air velocity																																																																
Unit	Range	Resolution	Threshold	Accuracy																																																												
M/s	0~30	0.1	0.1	± 5%																																																												
Ft/min	0~5860	19	39																																																													
Knots	0~55	0.2	0.1																																																													
Km/hr	0~90	0.3	0.3																																																													
Mph	0~65	0.2	0.2																																																													
B. Temperature																																																																
Unit	Range	Resolution	Accuracy																																																													
°C	-10°C~+45°C	0.2	± 2°C																																																													
°F	-14°F~+113°F	0.36	± 3.6°C																																																													
Battery	CR2032 3.0V (Included)																																																															
Thermometer	NTC Thermometer																																																															
Operating temperature	-10°C~+45°C(4°F~113°F)																																																															
Operating humidity	Less than 90% RH																																																															
Store temperature	-40°C~+60°C(-40°F~140°F)																																																															
Current consumption	Approx. 3mA																																																															

BACK PART

<p>21243_Anemometer Balest User manual (Eng)</p>  <p>It is recommended to read this user manual carefully and keep it for future reference.</p>	<p>Product Overview:</p>  <p>Functions:</p> <ol style="list-style-type: none"> Air velocity & temperature measurement Max/Average/Current air velocity measurement °C/°F Temperature unit selection Five units of air velocity: M/s, Km/h, ft/min, knots, mph Beaufort scale Backlight display Manual/Auto power shut off Wind chill indication Low battery indication 	<p>LCD Display:</p>  <p>Operation:</p> <ol style="list-style-type: none"> Turn on: Press "MODE" button for 2 seconds to turn on the unit. LCD will display Air velocity, temperature and battery icon. LCD backlight will last for 12 seconds. Set unit of air velocity and measuring mode: Press "MODE" button more than 3 seconds until "m/s" starts to blink. Press "SET" button to select desired air velocity unit. To confirm the unit, press "MODE" button. For setting MAX/AVG/CU mode, press "SET" button again and again until CU/MAX/AVG blink, then press "MODE" button to confirm. Measurement: When the wind vane (impeller) turns, LCD will instant display wind speed, temperature and beaufort scale. When temperature below 0 °C, "WIND CHIL" will be shown on the LCD. Turn off: Press "MODE" + "SET" buttons at the same time to turn off the unit. Auto power shut off: The unit will be shut off without any operation for 14 minutes. Change battery: When the symbol "—" shown on the LCD, please change the battery. 	<p>3. Set temperature unit: Temperature switch key (°C/F) conceal in the rear cabinet, please use a little push-pin to press the key for (°C/F) conversion.</p> <p>4. Backlight display: The backlight will be activated for 12 seconds by press any key.</p> <p>5. Measurement: When the wind vane (impeller) turns, LCD will instant display wind speed, temperature and beaufort scale. When temperature below 0 °C, "WIND CHIL" will be shown on the LCD.</p> <p>6. Turn off: Press "MODE" + "SET" buttons at the same time to turn off the unit.</p> <p>7. Auto power shut off: The unit will be shut off without any operation for 14 minutes.</p> <p>8. Change battery: When the symbol "—" shown on the LCD, please change the battery.</p>	<p>Especificaciones:</p> <table border="1"> <thead> <tr> <th colspan="5">A. Air velocity</th> </tr> <tr> <th>Unit</th> <th>Range</th> <th>Resolution</th> <th>Threshold</th> <th>Accuracy</th> </tr> </thead> <tbody> <tr> <td>M/s</td> <td>0~30</td> <td>0.1</td> <td>0.1</td> <td rowspan="4">± 5%</td> </tr> <tr> <td>Ft/min</td> <td>0~5860</td> <td>19</td> <td>39</td> </tr> <tr> <td>Knots</td> <td>0~55</td> <td>0.2</td> <td>0.1</td> </tr> <tr> <td>Km/hr</td> <td>0~90</td> <td>0.3</td> <td>0.3</td> </tr> <tr> <td>Mph</td> <td>0~65</td> <td>0.2</td> <td>0.2</td> </tr> </tbody> </table> <table border="1"> <thead> <tr> <th colspan="4">B. Temperature</th> </tr> <tr> <th>Unit</th> <th>Range</th> <th>Resolution</th> <th>Accuracy</th> </tr> </thead> <tbody> <tr> <td>°C</td> <td>-10°C~+45°C</td> <td>0.2</td> <td>± 2°C</td> </tr> <tr> <td>°F</td> <td>-14°F~+113°F</td> <td>0.36</td> <td>± 3.6°C</td> </tr> </tbody> </table> <table border="1"> <thead> <tr> <th>Battery</th> <th>CR2032 3.0V (Included)</th> </tr> </thead> <tbody> <tr> <td>Thermometer</td> <td>NTC Thermometer</td> </tr> <tr> <td>Operating temperature</td> <td>-10°C~+45°C(4°F~113°F)</td> </tr> <tr> <td>Operating humidity</td> <td>Less than 90% RH</td> </tr> <tr> <td>Store temperature</td> <td>-40°C~+60°C(-40°F~140°F)</td> </tr> <tr> <td>Current consumption</td> <td>Approx. 3mA</td> </tr> </tbody> </table>	A. Air velocity					Unit	Range	Resolution	Threshold	Accuracy	M/s	0~30	0.1	0.1	± 5%	Ft/min	0~5860	19	39	Knots	0~55	0.2	0.1	Km/hr	0~90	0.3	0.3	Mph	0~65	0.2	0.2	B. Temperature				Unit	Range	Resolution	Accuracy	°C	-10°C~+45°C	0.2	± 2°C	°F	-14°F~+113°F	0.36	± 3.6°C	Battery	CR2032 3.0V (Included)	Thermometer	NTC Thermometer	Operating temperature	-10°C~+45°C(4°F~113°F)	Operating humidity	Less than 90% RH	Store temperature	-40°C~+60°C(-40°F~140°F)	Current consumption	Approx. 3mA	<p>Advertencias:</p> <ol style="list-style-type: none"> No lo exponga a la lluvia o entornos mojados. Evite caídas que le puedan generar daños serios. No intente reparar la unidad por sí mismo, contacte con un especialista. Para evitar riesgos, no se deshaga de él de manera inapropiada. Limpíelo con un trapo seco. No lo instale cerca de fuentes de calor o luz solar directa. No inserte ningún objeto metálico en la unidad, existiría la posibilidad de un cortocircuito. Mantenga fuera del alcance de los niños. <p>CE MADE IN PRC</p> <p> This symbol both in the product and its user manual indicates that at the end of the device's electrical life, it should be recycled separately from your household waste. There are adequate means to dispose of this material for proper recycling. For more information, contact your local authorities.</p> <p>Hereby, Miko Catal Importaciones S.L., declares that this radio equipment is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at: www.makito.eu (search on reference).</p> <p>MIKO CATAL IMPORTACIONES S.L., B04267225 Ctra. de Huércal-Overa, s/n, 04640, Pulpi, Almería, Spain.</p>
A. Air velocity																																																																
Unit	Range	Resolution	Threshold	Accuracy																																																												
M/s	0~30	0.1	0.1	± 5%																																																												
Ft/min	0~5860	19	39																																																													
Knots	0~55	0.2	0.1																																																													
Km/hr	0~90	0.3	0.3																																																													
Mph	0~65	0.2	0.2																																																													
B. Temperature																																																																
Unit	Range	Resolution	Accuracy																																																													
°C	-10°C~+45°C	0.2	± 2°C																																																													
°F	-14°F~+113°F	0.36	± 3.6°C																																																													
Battery	CR2032 3.0V (Included)																																																															
Thermometer	NTC Thermometer																																																															
Operating temperature	-10°C~+45°C(4°F~113°F)																																																															
Operating humidity	Less than 90% RH																																																															
Store temperature	-40°C~+60°C(-40°F~140°F)																																																															
Current consumption	Approx. 3mA																																																															