

RELOJ INTELIGENTE



4623 Manual

INTRODUCCIÓN ¿QUÉ INCLUYE?



Rastreador

Correa

Colgador

Cable USB

CONFIGURACIÓN

REQUISITOS DEL TELÉFONO MÓVIL:

El reloj 4623 puede ser configurado y sincronizado con ciertos móviles que soporten tecnología Bluetooth.

iOS 7.0 o superior (iPhone 4S/5/5S/6, iPad3/4, iPad mini/mini2).

Android 4.3 o superior (Nexus 4/5/7, Samsung S3/S4/S5, SONY Z1/Z2, MI 3/4, HTC ONE/M8, LG G2/G3, Huawei P7/G6, MOTO X/G, etc).

CONFIGURAR HPLUS APP:


A diferencia de la mayoría de accesorios Bluetooth, tu 4623 debe interconectar directamente a través de "Hplus" APP y no a través del Bluetooth de tu Android / iOS. Busque y descargue "HPlus Watch" APP desde iOS APP store o Android Google Playstore.

CONECTA Y SINCRONIZA:



1. Asegúrese de que el Bluetooth de su smartphone esté conectado.

Pulse :

"HPlus" APP, presione Configuración > Conectar > Bluetooth



2. Haga doble clic en su rastreador y "HPlus" APP buscará su aparato Bluetooth. Seleccione el aparato, entonces la APP mostrará Bluetooth conectado.




3. Pulse sincronizar, cuando el proceso finalice, verá los datos del día. Puede que la primera sincronización de los equipos tarde más de lo habitual.




PREGUNTAS FRECUENTES

1. Siga el cuadro de abajo para abrir configuración > recordatorio de llamada. Este programa si es ejecutado en segundo plano consumirá muy poca energía. Cuando su móvil reciba una llamada, el reloj inteligente vibrará de manera que emitirá una vibración corta, larga y luego corta de nuevo y el número de teléfono se visualizará en la pantalla. Haga doble clic para cancelar.




2. En el siguiente cuadro se pueden establecer varias alarmas inteligentes. Tenga en cuenta que la "Hora de inicio" es la hora desde que quiere que empiecen a vibrar las alarmas con el "Intervalo" que arriba se indique y hasta la "Hora de finalización" que se deseé. De este modo si se quiere activar el recordatorio "Tomar medicación" cada 1 hora, deberá indicar por ejemplo 1 hora en el "Intervalo" con una "Hora de inicio" las 08.00 y una "Hora de finalización" las 21.00. Así el recordatorio se activará cada 1 hora a partir de la "Hora de inicio" hasta la "Hora de finalización". Vea la imagen de más abajo.

Las diferentes alarmas tienen diferentes vibraciones. (Notificación de "Mensajes" solo para Android).



3. Función antipérdida por Bluetooth. Evite perder el contacto con sus posesiones valiosas. En el momento en el que el rastreador se aleje más de 10 metros del teléfono móvil, saltará una alarma automáticamente. (SOLO PARA ANDROID)



4. El reloj inteligente puede registrar y mostrar los pasos, consumo de calorías y distancia recorrida. Pulsando en la superficie de la esfera del reloj inteligente podemos cambiar las diferentes pantallas de funciones que muestra. Los datos se pueden consultar en su móvil a través de la aplicación una vez haya sido sincronizado.



5. Pulse la superficie del reloj inteligente para pasar a la pantalla del modo sueño. Luego pulse dos veces para activar la función de control del sueño. Haga 2 veces doble clic para salir de la función de control del sueño.



ESPECIFICACIONES

MCU	Nordic ARM Cortex M0
Bluetooth	Bluetooth Low Energy (4.0)
G-Sensor	ADI 3 Axis Accelerometer
Motor	Micro Vibrator Motor
Pantalla	0.68" OLED 96X32
Batería	60mAh
Tiempo en espera	5~8 Días
Grabación de datos	30 Días
Peso	27g

RASTREADOR



38mm



10mm

CORREA



260mm

ESTRONG

SMART WATCH



4623 Manual

GETTING STARTED

WHAT IS INCLUDED?



SETTING UP

SMART MOBILE DEVICE REQUIREMENT:

The 4623 is capable of setting up and syncing with select mobile devices that support bluetooth technology.

iOS 7.0 and above (iPhone 4S/5/5S/6, iPad3/4, iPad mini/mini2).

Android 4.3 and above (Nexus 4/5/7, Samsung S3/S4/S5, SONY Z1/Z2, MI 3/4, HTC ONE/M8, LG G2/G3, Huawei P7/G6, MOTO X/G, etc).


SETUP HPLUS APP:

Unlike most bluetooth accessories, your 4623 must be paired directly through the "Hplus" APP and not through your Android / iOS bluetooth settings. Search and download "HPlus Watch" APP from your iOS APP store or Android Google Playstore.



CONNECT & SYNC:

1. Make sure your smart mobile device bluetooth is ON.


Click "HPlus" APP, tap Setting > Connect > Bluetooth



2. Double click your tracker and "HPlus" APP will search bluetooth device. Select the device, then the APP will show bluetooth connected.




3. Press Sync, when it is complete, you will see Today Data. The first time the devices are synchronized may take longer.



FAQ


1. Follow the chart below to open settings > call reminder. The software running in the background uses only very little battery power. When the mobile Phone receives calls, the Smart watch will vibrate in the way of short, long, then short vibrations and the phone number will be displayed on the screen. Double click to cancel.




2. The following chart can set various smart alerts.

Please take into account that "Start time" is the time you want to begin receiving notification alarms with "Interval Time" set above, until the "End time" you desire. For example, to activate the alarm "Take your medication" every hour, you must set "Interval time" 1 hour with "Start time" at 08.00 and "End time" at 21.00. This Way you will receive a notification every hour from the set "Start time" to the set "End time". See picture below.

Different alerts have different vibrations. (Message notification only for Android)



3. Bluetooth anti-lost function. Keeping you in contact with your valued possessions. When the tracker goes more than 10 meters distance from the mobile phone, your mobile phone will automatically alarm. (ONLY FOR ANDROID)



4. The Smart watch can record and display steps, calorie consumption and walking distance. Clicking the Smart watch surface can switch different display interface. The data can be checked in your smart devices after it has been synchronized.



5. Click the Smart watch surface to sleep display. Then Double click to change to sleep monitoring record function. Two consecutive double clicks will sign out of the sleep monitoring record function.



PARAMETER

MCU	Nordic ARM Cortex M0
Bluetooth	Bluetooth Low Energy (4.0)
G-Sensor	ADI 3 Axis Accelerometer
Motor	Micro Vibrator Motor
Display	0.68" OLED 96X32
Battery	60mAh
Standby Time	5~8 Days
Date Record	30 Days
Weight	27g

TRACKER



38mm



10mm

WRISTBAND



260mm

ST500